

Connect the corners



1 Lift FASTclamp lever and fully insert the 90° L-bracket. Lock clamp by pressing lever back down into the channel. Repeat for both clamps on this frame profile.



2 Insert the brackets of the first profile into the Fastclamp grooves of the second profile.




3 Lock the FASTclamp and make the same in all 4 corners.

Connect the straight profile



1 Lift the FASTclamp lever while inserting the profile stem. Make sure that the small metal bracket is in direct contact with the FASTclamp.



2 Push together.



3 Lock the FASTclamp.

Connect the twist-in foot



1 Attach the foot parallel to the profile, at any desired position.



2 Twist the foot to lock in place. Foot can be twisted in either direction, depending on which end you prefer for the front of your display.



3 Twist to 90° and stop.

**Frame size**

**Outer size** (width x height) of aluminium frame. Same sizes as stated in the price list.

Please note that these sizes are for A-type frames which are **not connected** to another frame in **90° angle**. For B- and C-type frames, which are connected on one side alternatively both sides, frame sizes must be reduced as follows:


- For **B-type** frames reduce frame width by **37 mm**
- For **C-type** frames reduce frame width by **74 mm**

**Important!**

**Fabric Frames in shell scheme stands**

In case you plan to use our Fabric Frames in a shell scheme exhibition stand please be sure to get the exact floor space measurements from the exhibition organizer. Normally you need to customize (reduce size of the frame) to be able to fit it in.

Example: Plan view of 3x2 meter exhibition stand



**Information for producing artwork / graphic file**

**Fabric graphic size**

“Frame size” + 6 mm/each side

**Visible graphic size**


“Frame size” - 3 mm/each side

**Information for printing the fabric**

**Fabric print size**

The actual “Fabric print size” is normally not the same as the “Fabric graphic size” because of the stretch and other properties of the specific fabric material chosen. The “Fabric Print size” therefore has to be decided by the printing company and Mark Bric cannot be held responsible for problems arising from any fabric print.

*All textiles behave differently depending on the material type, weave orientation, stretch, shrinkage and other factors such as humidity, temperature and method of printing. Always ensure you test any new material and allow time for the test print to exhibit shrinkage or stretch whilst fitted to a frame.*



**Attaching PVC-strip**

A PVC-strip must be stitched to the edges of the fabric. Sewing seam to be placed 2-3 mm from the edge of the fabric/strip.

**Cutting corners**

In each corner cut off 14 mm as shown on the picture to be able to attach the graphic neatly to the frame.

