

## Simple, inexpensive, corner brackets for ISOframe Fabric

### Option 1 – Inside corner solution



IS-9306

Use these simple corner brackets to form 90-degree inside corners with these easy steps:

- Build separate frames horizontally, on the floor, complete with fabric panel installation, prior to raising the wall.
- Raise the frames independently, form the corner, and connect the frames on the reverse side using two connection brackets (IS-9306).
- Use three brackets per corner for frames 2m or less in height. Add another bracket for each additional meter of height.
- 37 mm of the graphic print on one frame becomes hidden in this construction – **please design your graphics accordingly.**

**The low cost, simple design and construction provided by this solution are major advantages.**

### Option 2 – Outside corner solution



Use these simple corner brackets to form 90-degree outside corners with these easy steps:

- Build separate frames horizontally, on the floor, complete with fabric panel installation, prior to raising the wall.
- Raise the frames independently, form the corner, and connect the frames on the reverse side using two connection brackets (IS-9306).
- Use three brackets per corner for frames 2m or less in height. Add another bracket for each additional meter of height.
- 37 mm of framing profile will now separate the front panel from the side panels – **please design your graphics accordingly**, with no need for continuous wrap-around images.

### Option 3 – Side-by-side connection



Use these simple brackets to form a straight wall with 2 frames or more with these easy steps:

- Build separate frames horizontally, on the floor, complete with fabric panel installation, prior to raising the wall.
- Raise the frames independently, side-by-side and connect the frames on the reverse side using two connection brackets (IS-9306).
- Use three brackets per corner for frames 2m or less in height. Add another bracket for each additional meter of height.

**A straight wall has no stability. Make a 90° corner or use Arched side feet (IS-9342) at each end of the wall.**

